

Component Procedures: Brake Warning Indicator

Table of Contents

1. Components (itype_392)
2. Technician Safety Information (itype_15)
3. Component Tests and General Diagnostics (itype_383)

Component Procedures: Brake Warning Indicator

Components (itype_392)

A red

warning lamp

is used for the service brake portion of the hydraulic system

. The lamp is located in the instrument cluster

. The red warning light alerts the driver if a pressure differential exists between the front and rear hydraulic systems or the parking brake s are applied.

The lamp is turned on momentarily when the ignition switch is turn to the ON position. This is a self test to verify the lamp is operational.

Technician Safety Information (itype_15)

WARNING: ON VEHICLES EQUIPPED WITH AIRBAGS, REFER TO RESTRAINT SYSTEMS / AIRBAG SYSTEMS BEFORE ATTEMPTING A STEERING WHEEL, STEERING COLUMN, OR INSTRUMENT PANEL

COMPONENT DIAGNOSIS OR SERVICE. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIRBAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY

.

Component Tests and General Diagnostics (itype_383)

Each of the lamps depends upon a hard wired circuit input to the instrument cluster

for proper operation. The following procedures will help to diagnose conditions that may cause an inoperative hard wired lamp circuit condition.

WARNING: ON VEHICLES EQUIPPED WITH AIR-BAGS, REFER TO AIRBAG AND SEAT BELTS/AIR BAGS BEFORE ATTEMPTING ANY STEERING WHEEL, STEERING COLUMN, OR INSTRUMENT PANEL

COMPONENT DIAGNOSIS OR SERVICE. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIR-BAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY

INOPERATIVE LAMP

1. Check the fused ignition switch output (run/ start) fuse in the fuseblock module. If OK, go to Step 2. If not OK, repair the shorted circuit or component as required and replace the faulty fuse.

2. Turn the ignition switch to the On position. Check for battery voltage at the fused ignition switch output (run/start) fuse in the fuseblock module. If OK, go to Step 3. If not OK, repair the open fused ignition switch output (run/start) circuit to the ignition switch as required.

3. Turn the ignition switch to the Off position. Disconnect and isolate the battery negative cable. Disconnect the wire harness connector at the park brake switch

. With the park brake

released, check for continuity between the park brake switch terminal and a good ground. There should be no continuity. If OK, go to Step 4. If not OK, adjust or replace the faulty park brake switch.

4. Disconnect the wire harness connector at the brake warning switch. Check for continuity between the two terminals of the brake warning switch. There should be continuity. If OK, go to Step 5. If not OK, replace the faulty brake warning switch.

5. Check for continuity between each of the two brake warning switch terminals and a good ground. In each case, there should be no continuity. If OK, go to Step 6. If not OK, replace the faulty brake warning switch.

6. With both the park brake switch and the brake warning switch wire harness connectors still disconnected, check for continuity between the red

brake warning indicator

driver circuit cavity of the park brake switch wire harness connector and a good ground. There should be no continuity If OK, go to Step 7. If not OK, repair the shorted red brake warning indicator driver circuit as required.

7. With the ignition switch held in the Start position, check for continuity between the red brake warning indicator driver circuit cavity of the park brake switch wire harness connector and a good ground. There should be continuity. If OK, go to Step 8. If not OK, repair the open red brake warning indicator driver circuit to the ignition switch as required.

8. Turn the ignition switch to the Off position. Remove the instrument cluster

. Check for continuity between the red brake warning indicator driver circuit cavity of the instrument cluster wire harness connector A and a good ground. There should be no continuity. If OK, go to Step 9. If not OK, repair the shorted red brake warning indicator driver circuit as required.

9. Check for continuity between the red brake warning indicator driver circuit cavities of the instrument cluster wire harness connector A and the brake warning switch wire harness connector. There should be continuity. If OK, replace the faulty bulb. If not OK, repair the open red brake warning indicator driver circuit as required.

LAMP STAYS ON

The

red brake warning lamp

will illuminate under the following conditions:

- Self test at start-up.

-

Parking brake

s are applied.

- Leak in front/rear brake hydraulic circuit.

If the red light remains on after start-up, first verify that the parking brakes are fully released. Then check pedal action and fluid level. If the lamp is on and the brake pedal

is low, this indicates the pressure differential switch and valve have been actuated due to a leak in the hydraulic system

On models with

ABS

brakes, the amber

warning lamp

only illuminates during the self test and when an ABS malfunction has occurred. The ABS lamp operates independently of the red warning lamp.