

Component Procedures: Fuel Filler Cap

Table of Contents

1. Components (itype_392)
2. Fuel Tank Filler Tube Cap Replacement (Article 2034640)

Component Procedures: Fuel Filler Cap

Components (itype_392)

SYSTEM OPERATION
FUEL TANK FILLER TUBE
CAP

The loss of any fuel or vapor out of filler neck is prevented by the use of a pressure-vacuum fuel tank

filler tube cap. Relief valves inside the cap will release fuel tank pressure at predetermined pressures. Fuel tank vacuum will also be released at predetermined values. This cap must be replaced by a similar unit if replacement is necessary. This is in order for the system to remain effective.

CAUTION

: Remove fuel tank filler tube cap before servicing any fuel system

component. This is done to help relieve tank pressure. If equipped with a California emissions package and a Leak Detection Pump

(
LDP

), the secondary seal below the fill cap must be pressed (opened) to relieve fuel tank pressure.

Fuel Tank Filler Tube Cap Replacement (Article 2034640)

REMOVAL AND INSTALLATION

If replacement of the fuel tank filler tube

cap is necessary, it must be replaced with an identical cap to be sure of correct system operation.

CAUTION

: Remove the fuel tank

filler tube cap to relieve fuel tank pressure. The cap must be removed prior to disconnecting any fuel system

component or before draining the fuel tank.