

# **Component Procedures: Body Control Systems**

## **Table of Contents**

1. Components (itype\_392)
2. Initial Inspection and Diagnostic Overview (itype\_377)
3. Reading Diagnostic Trouble Codes (Article 1469112)
4. Clearing Diagnostic Trouble Codes (Article 1469113)

# Component Procedures: Body Control Systems

## Components (itype\_392)

### Flowchart

- Use the following flowchart to verify the cause of the trouble.

STEP	INSPECTION	ACTION	
1	<b>INSPECT DTC INDICATION</b> <ul style="list-style-type: none"> <li>Using the M-MDS, inspect if DTCs are displayed for the following module:                             <ul style="list-style-type: none"> <li>PCM</li> <li>TCM</li> <li>EHPAS control module</li> <li>DSC HU/CM</li> <li>ABS HU/CM</li> <li>TPMS control module</li> <li>Instrument cluster</li> <li>Climate control unit</li> <li>SAS control module</li> <li>PJB</li> </ul> </li> <li>Using the self-diagnostic function, inspect if DTCs are displayed for the following module:                             <ul style="list-style-type: none"> <li>Information display</li> </ul> </li> <li>Are any DTCs displayed?</li> </ul>	Yes	Go to the next step.
		No	Go to Step 5.
2	<b>INSPECT CAN SYSTEM-RELATED DTC</b> <ul style="list-style-type: none"> <li>Are any DTCs other than the following displayed?                             <ul style="list-style-type: none"> <li>U0073</li> <li>U0100</li> <li>U0101</li> <li>U0121</li> <li>U0127</li> <li>U0131</li> <li>U0140</li> <li>U0151</li> <li>U0155</li> <li>U0164</li> <li>U0181</li> <li>U0184</li> <li>U0516</li> <li>U1900</li> <li>U2012</li> <li>U2023</li> <li>U2202</li> <li>U2516</li> <li>U2523</li> </ul> </li> </ul>	Yes	Repair the malfunctioning part by following the related DTC inspection. Go to the next step.
		No	Go to the next step.


STEP	INSPECTION	ACTION	
3	<b>INSPECT CAN SYSTEM-RELATED DTC</b> <ul style="list-style-type: none"> <li>Are any of the following DTCs displayed?                             <ul style="list-style-type: none"> <li>PCM: U0073, U0101, U0121, U0155</li> <li>TCM: U0073, U0100</li> <li>EHPAS control module: U0073, U0100, U2023</li> <li>DSC HU/CM or ABS HU/CM: U1900, U2012, U2202, U2523</li> <li>TPMS control module: U0073</li> <li>Instrument cluster: U0073, U0100, U0101, U0121, U0127, U0131, U0140, U0151, U0184, U2516</li> <li>Climate control unit: U0140, U0155, U0184, U0516</li> <li>SAS control module: U0073, U1900</li> <li>Information display: U0164, U0181, U0184, U2516</li> <li>PJB: U1900</li> </ul> </li> </ul>	Yes	Repair the malfunctioning part by following the DTC inspection. Go to the next step.
		No	Troubleshooting completed.
4	<b>VERIFY TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Clear the DTC from the CAN system-related modules using the M-MDS.</li> <li>Start the engine.</li> <li>Are any of the CAN related DTCs displayed?</li> </ul>	Yes	Go back to Step 3.
		No	Troubleshooting completed.
5	<b>INSPECT COMMUNICATION CONDITION</b> <ul style="list-style-type: none"> <li>Is there a response from the following modules?                             <ul style="list-style-type: none"> <li>PCM</li> <li>TCM</li> <li>EHPAS control module</li> <li>DSC HU/CM</li> <li>ABS HU/CM</li> <li>TPMS control module</li> <li>Instrument cluster</li> <li>Climate control unit</li> <li>SAS control module</li> <li>PJB</li> </ul> </li> </ul>	Yes	Troubleshooting completed.
		No	Go to the next step.
6	<b>INSPECT MODULES THAT DO NOT RESPOND</b> <ul style="list-style-type: none"> <li>Inspect the power supply and the ground circuit for any units that do not respond.</li> <li>Are they normal?</li> </ul>	Yes	Go to the next step.
		No	Repair the malfunctioning part, then go back to Step 1.

STEP	INSPECTION	ACTION	
7	<b>INSPECT CONNECTOR AND WIRING HARNESS BETWEEN MODULES THAT DO NOT RESPOND AND DLC-2</b> <ul style="list-style-type: none"> <li>Turn the ignition switch to the LOCK position.</li> <li>Inspect the wiring harness and connector between any module that does not respond and the DLC-2.</li> </ul> <b>PCM—DLC-2</b> <ul style="list-style-type: none"> <li>1AM—F</li> <li>1AI—F</li> </ul> <b>TCM—DLC-2</b> <ul style="list-style-type: none"> <li>B—F</li> <li>E—E</li> </ul> <b>EHPAS control module—DLC-2</b> <ul style="list-style-type: none"> <li>2B—F</li> <li>2H—E</li> </ul> <b>DSC HU/CM—DLC-2</b> <ul style="list-style-type: none"> <li>P—F</li> <li>D—E</li> </ul> <b>ABS HU/CM—DLC-2</b> <ul style="list-style-type: none"> <li>H—F</li> <li>L—E</li> </ul> <b>Instrument cluster—DLC-2</b> <ul style="list-style-type: none"> <li>1I—F</li> <li>1K—E</li> <li>1M—L</li> <li>1O—L</li> </ul> <b>Climate control unit—DLC-2</b> <ul style="list-style-type: none"> <li>X—L</li> <li>W—K</li> </ul> <b>SAS control module—DLC-2</b> <ul style="list-style-type: none"> <li>1X—L</li> <li>1T—K</li> </ul> <b>PJB—DLC-2</b> <ul style="list-style-type: none"> <li>J-04 D—L</li> <li>J-04 B—K</li> </ul>	Yes	Go to the next step.
		No	Repair the malfunctioning part, then go back to Step 1.
8	<b>INSPECT WIRING HARNESS</b> <ul style="list-style-type: none"> <li>Turn the ignition switch to the ON position (Engine off).</li> <li>Measure the voltage between the following terminals <ul style="list-style-type: none"> <li>DLC-2 terminals F and E</li> <li>DLC-2 terminals L and K</li> </ul> </li> <li>Is the voltage 2.8—3.0 V?</li> </ul>	Yes	Go to the next step.
		No	Go to Step 12.
9	<b>INSPECT WIRING HARNESS</b> <ul style="list-style-type: none"> <li>Turn the ignition switch to the LOCK position.</li> <li>Measure the resistance between the following terminals <ul style="list-style-type: none"> <li>DLC-2 terminals F and E</li> <li>DLC-2 terminals L and K</li> </ul> </li> <li>Is the resistance 59—65 ohms?</li> </ul>	Yes	Replace the modules that do not respond, then go back to Step 1.
		No	Go to the next step.
10	<b>INSPECT PCM</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Measure the resistance between following terminals <ul style="list-style-type: none"> <li>PCM terminals 1AM and 1AI (part-side)</li> </ul> </li> <li>Is the resistance 118—130 ohms?</li> </ul>	Yes	Go to the next step.
		No	Replace the PCM, then go to the next step.
11	<b>INSPECT INSTRUMENT CLUSTER</b> <ul style="list-style-type: none"> <li>Disconnect the instrument cluster connector.</li> <li>Measure the resistance between the following terminals <ul style="list-style-type: none"> <li>Instrument cluster terminals 1I and 1K (part-side)</li> <li>Instrument cluster terminals 1M and 1O (part-side)</li> </ul> </li> <li>Is the resistance 118—130 ohms?</li> </ul>	Yes	Go to next step.
		No	Replace the instrument cluster, then go to the next step.

STEP	INSPECTION	ACTION	
12	<b>CLASSIFY WIRING HARNESS MALFUNCTION OR MODULE MALFUNCTION</b> <ul style="list-style-type: none"> <li>Turn the ignition switch to the LOCK position.</li> <li>Disconnect the connector of any unit that does not respond. (If there are two or more units that do not respond, disconnect only one of the units.)</li> <li>Turn the ignition switch to the ON position.</li> <li>Measure the voltage between the following terminals <ul style="list-style-type: none"> <li>DLC-2 terminals F and E</li> <li>DLC-2 terminals L and K</li> </ul> </li> <li>Is voltage 2.8—3.0 V?</li> </ul>	Yes	Go to the next step.
		No	Retry this step with other module connector disconnected. If all units that do not respond are disconnected, go to Step 14.
13	<b>INSPECT WIRING HARNESS OF ANY UNIT THAT DOES NOT RESPOND</b> <ul style="list-style-type: none"> <li>Turn the ignition switch to the LOCK position.</li> <li>Inspect for continuity between the following connector terminals of any disconnected unit. <ul style="list-style-type: none"> <li><b>PCM</b> <ul style="list-style-type: none"> <li>1AM—other terminals</li> <li>1AI—other terminals</li> </ul> </li> <li><b>TCM</b> <ul style="list-style-type: none"> <li>B—other terminals</li> <li>E—other terminals</li> </ul> </li> <li><b>EHPAS control module</b> <ul style="list-style-type: none"> <li>2B—other terminals</li> <li>2H—other terminals</li> </ul> </li> <li><b>DSC HU/CM</b> <ul style="list-style-type: none"> <li>P—other terminals</li> <li>D—other terminals</li> </ul> </li> <li><b>ABS HU/CM</b> <ul style="list-style-type: none"> <li>H—other terminals</li> <li>L—other terminals</li> </ul> </li> <li><b>Instrument cluster</b> <ul style="list-style-type: none"> <li>1I—other terminals</li> <li>1K—other terminals</li> <li>1M—other terminals</li> <li>1O—other terminals</li> </ul> </li> <li><b>Climate control unit</b> <ul style="list-style-type: none"> <li>X—other terminals</li> <li>W—other terminals</li> </ul> </li> <li><b>SAS control module</b> <ul style="list-style-type: none"> <li>1X—other terminals</li> <li>1T—other terminals</li> </ul> </li> <li><b>PJB</b> <ul style="list-style-type: none"> <li>J-04 D—other terminals</li> <li>J-04 B—other terminals</li> </ul> </li> </ul> </li> <li>Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness, then go back to Step 1.
		No	Replace the disconnected unit, then go back to Step 1.
14	<b>INSPECT CAN RELATED WIRING HARNESS</b> <ul style="list-style-type: none"> <li>Inspect the related wiring harnesses (CAN_L and/or CAN_H) for the short circuit (to power supply or ground).</li> <li>Is the wiring harness normal?</li> </ul>	Yes	Repair or replace the wiring harness, then go back to Step 1.
		No	Go back to Step 1.

## Initial Inspection and Diagnostic Overview (itype\_377)

**System Wiring Diagram**



e3u0902wu01

x: Normal  
 —: Communication error

Module	Communication status			Malfunction location
	TCM	DSC HU/CM ABS HU/CM	Instrument cluster	
PCM	—	—	—	<ul style="list-style-type: none"> <li>Wiring harness A</li> <li>PCM</li> </ul>
	—	x	x	<ul style="list-style-type: none"> <li>Wiring harness B</li> <li>TCM</li> </ul>
	x	—	—	<ul style="list-style-type: none"> <li>Wiring harness C</li> <li>Wiring harness E</li> </ul>
	x	—	x	<ul style="list-style-type: none"> <li>Wiring harness F</li> <li>DSC HU/CM</li> <li>ABS HU/CM</li> </ul>
	x	x	—	<ul style="list-style-type: none"> <li>Wiring harness G</li> <li>Instrument cluster</li> </ul>

x: Normal  
 —: Communication error

Module	Communication status		Malfunction location
	PCM		
TCM	—		<ul style="list-style-type: none"> <li>Wiring harness A</li> <li>Wiring harness B</li> <li>TCM</li> <li>PCM</li> </ul>

x: Normal  
 —: Communication error

Module	Communication status		Malfunction location
	PCM		
EHPAS control module	—		<ul style="list-style-type: none"> <li>Wiring harness A</li> <li>Wiring harness C</li> <li>Wiring harness D</li> <li>EHPAS control module</li> <li>PCM</li> </ul>

×: Normal  
 —: Communication error

Module	Communication status		Malfunction location
	PCM		
ABS HU/CM	—		<ul style="list-style-type: none"> <li>• Wiring harness A</li> <li>• Wiring harness C</li> <li>• Wiring harness E</li> <li>• Wiring harness F</li> <li>• PCM</li> </ul>

×: Normal  
 —: Communication error

Module	Communication status					Malfunction location
	PCM	TCM	EHPAS control module	DSC HU/CM ABS HU/CM	TPMS control module	
Instrument cluster	—	—	—	—	—	• Instrument cluster
	—	×	×	×	×	• Wiring harness A • PCM
	×	—	×	×	×	• Wiring harness B • TCM
	—	—	×	×	×	• Wiring harness C
	×	×	—	×	×	• Wiring harness D • EHPAS control module
	—	—	—	×	×	• Wiring harness E
	×	×	×	—	×	• Wiring harness F • DSC HU/CM • ABS HU/CM
	×	×	×	×	—	• TPMS control module

×: Normal  
 —: Communication error

Module	Communication status			Malfunction location
	PJB	SAS control module	Audio unit (base module)	
Instrument cluster	—	—	—	• Wiring harness I • Instrument cluster
	—	×	×	• Wiring harness L • PJB
	×	—	×	• Wiring harness K • SAS control module
	×	×	—	• Wiring harness J • Audio unit (base module)

×: Normal  
 —: Communication error

Module	Communication status			Malfunction location
	PJB	Instrument cluster	Audio unit (base module)	
Climate control unit	—	—	—	• Wiring harness H • Climate control unit
	—	×	×	• Wiring harness L • PJB
	×	—	×	• Wiring harness I • Instrument cluster
	×	×	—	• Wiring harness J • Audio unit (base module)

×: Normal  
 —: Communication error

Module	Communication status		Malfunction location
	Instrument cluster		
SAS control module	—		<ul style="list-style-type: none"> <li>• Wiring harness I</li> <li>• Wiring harness K</li> <li>• SAS control module</li> <li>• Instrument cluster</li> </ul>

×: Normal  
 —: Communication error

Module	Communication status			Malfunction location
	Climate control unit	Instrument cluster	Audio unit (base module)	
Information Display	—	—	—	<ul style="list-style-type: none"> <li>• Wiring harness M</li> <li>• Information Display</li> </ul>
	—	×	×	<ul style="list-style-type: none"> <li>• Wiring harness H</li> <li>• Climate control unit</li> </ul>
	×	—	×	<ul style="list-style-type: none"> <li>• Wiring harness I</li> <li>• Instrument cluster</li> </ul>
	×	×	—	<ul style="list-style-type: none"> <li>• Wiring harness J</li> <li>• Audio unit (base module)</li> </ul>

×: Normal  
 —: Communication error

Module	Communication status		Malfunction location
	Audio unit (base module)	Instrument cluster	
PJB	—		<ul style="list-style-type: none"> <li>• Wiring harness I</li> <li>• Wiring harness J</li> <li>• Wiring harness L</li> <li>• PJB</li> <li>• Audio unit (base module)</li> <li>• Instrument cluster</li> </ul>

### Reading Diagnostic Trouble Codes (Article 1469112)

Non Standards  
 - DTC Inspection (1433560)

### Clearing Diagnostic Trouble Codes (Article 1469113)

Non Standards  
 - With Manufacturer's Scan Tool (1469128)