

# **Component Procedures: Trunk Lamp**

## **Table of Contents**

1. Rear Compartment Lamp Malfunction (Article 10366)

# Component Procedures: Trunk Lamp

## Rear Compartment Lamp Malfunction (Article 10366)

### Diagnostic Instructions

- Perform the Diagnostic System Check - Vehicle prior to using this diagnostic procedure.
- Review Strategy Based Diagnosis for an overview of the diagnostic approach.
- Diagnostic Procedure Instructions provides an overview of each diagnostic category.

### Diagnostic Fault Information

Circuit Short to Ground Open/High Resistance Short to Voltage Signal Performance

Rear Compartment Courtesy Lamp Control B2570 02 B2570 04 B2570 01 —

Rear Compartment Courtesy Lamp Ground — 1 — —

### 1. Rear Compartment Lamp Malfunction

#### Circuit/System Description

The body control module (BCM) applies battery voltage to the rear compartment courtesy lamp through the rear compartment lamp control circuit. When the BCM receives a rear compartment lid open input from the rear compartment lid latch, the BCM applies battery voltage to the rear compartment lamp control circuit illuminating the rear compartment courtesy lamp. In the event that the rear compartment lamp were to remain illuminated for more than 10 minutes with the ignition switch in the OFF position and no doors opened, the BCM will deactivate the rear compartment lamp control circuit to prevent total battery discharge.

#### Reference Information

#### Schematic Reference

Interior Lights Schematics

Connector End View Reference

Component Connector End Views

#### Description and Operation

Interior Lighting Systems Description and Operation

#### Electrical Information Reference

- Circuit Testing
- Connector Repairs
- Testing for Intermittent Conditions and Poor Connections
- Wiring Repairs

#### Scan Tool Reference

Control Module References for scan tool information

#### Circuit/System Testing

- Ignition OFF, exterior lamps OFF, trunk latch latched, disconnect the harness connector at the E8S rear compartment courtesy lamp.
- Test for less than 5  $\Omega$  between the ground circuit terminal 2 and ground.
- If 5  $\Omega$  or greater
- Ignition OFF.
- Test for less than 2  $\Omega$  in the ground circuit end to end.
- If 2  $\Omega$  or greater, repair the open/high resistance in the circuit.
- If less than 2  $\Omega$ , repair the open/high resistance in the ground connection.
- If less than 5  $\Omega$
- Connect a test lamp between the control circuit terminal 1 and ground, ignition ON.
- Verify the test lamp turns ON and OFF when commanding the Trunk Lamp ON and OFF with a scan tool.
- If the test lamp is always OFF
- Ignition OFF, disconnect the X7 harness connector at the K9 body control module.
- Test for infinite resistance between the control circuit and ground.
- If less than infinite resistance, repair the short to ground on the circuit.
- If infinite resistance
- Test for less than 2  $\Omega$  in the control circuit end to end.
- If less than 2  $\Omega$ , replace the K9 body control module.
- If the test lamp is always ON
- Ignition OFF, disconnect the X7 harness connector at the K9 body control module, ignition ON.
- Test for less than 1 V between the control circuit terminal and ground.
- If 1 V or greater, repair the short to voltage on the circuit.
- If less than 1 V, replace the K9 body control module.
- If the test lamp turns ON and OFF
- Test or replace the E8S rear compartment courtesy lamp.

#### Repair Instructions

Perform the Diagnostic Repair Verification after completing the repair.

- Rear Compartment Courtesy Lamp Replacement
- Control Module References for BCM replacement, programming, and setup