

Component Procedures: Air Door Actuator / Motor

Table of Contents

1. Parts and Labor (itype_189)
2. Auto Defogging Actuator - Description and Operation (Article 44871)
3. Intake Actuator - Description and Operation (Article 44883)
4. Mode Control Actuator - Description and Operation (Article 44867)
5. Temperature Control Actuator - Description and Operation (Article 44860)
6. Auto Defogging Actuator - Components and Components Location (Article 44870)
7. Intake Actuator - Components and Components Location (Article 44882)
8. Mode Control Actuator - Components and Components Location (Article 44866)
9. Temperature Control Actuator - Components and Components Location (Article 44858)
10. Auto Defogging Actuator - Repair Procedures (Article 44873)
11. Intake Actuator - Repair Procedures (Article 44885)
12. Mode Control Actuator - Repair Procedures (Article 44869)
13. Temperature Control Actuator - Repair Procedures (Article 44864)
14. Auto Defogging Actuator - Specifications (Article 44872)
15. Intake Actuator - Specifications (Article 44884)
16. Mode Control Actuator - Specifications (Article 44868)
17. Temperature Control Actuator - Specifications (Article 44862)

Component Procedures: Air Door Actuator / Motor

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Controls > Door Actuator	971623SAA0	Intake	142.66	
Controls > Door Actuator	97154F2000	Mode Door	54.03	
Controls > Door Actuator > T?	97159F2010	Left	74.95	
Controls > Door Actuator > T?	97159F2000	Right	58.03	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Controls > Door Actuator, R&R > Auto Defogging	B	7.3	0.0
Remove & Replace	Controls > Door Actuator, R&R > Mode	B	7.3	0.0
Remove & Replace	Controls > Door Actuator, R&R > Recirculation	B	7.3	0.0
Remove & Replace	Controls > Door Actuator, R&R > Temperature >?	B	0.7	0.0
Remove & Replace	Controls > Door Actuator, R&R > Temperature >?	B	0.8	0.0

Auto Defogging Actuator - Description and Operation (Article 44871)

- Description

Intake Actuator - Description and Operation (Article 44883)

- Description

Mode Control Actuator - Description and Operation (Article 44867)


- Description

Temperature Control Actuator - Description and Operation (Article 44860)

- Description

Auto Defogging Actuator - Components and Components Location (Article 44870)


- Components Location



1. Auto logging actuator

Intake Actuator - Components and Components Location (Article 44882)


- Components Location



1. Intake actuator

Mode Control Actuator - Components and Components Location (Article 44866)


- Components Location



1. Mode control actuator

Temperature Control Actuator - Components and Components Location (Article 44858)


- Components Location



1. Temperature control actuator [LH] 2. Temperature control actuator [RH]

Auto Defogging Actuator - Repair Procedures (Article 44873)

- Inspection
- Turn the ignition switch OFF.
- Disconnect the auto defogging connector.
- Verify that the auto defogging actuator operates to the open position when connecting 12V to terminal 3 and grounding terminal 4. Verify that the auto defogging actuator operates to the close position when connected in reverse. Pin NO Function 1 - 2 - 3 Open 4 Sensor (+5V) 5 Feedback signal 6 Sensor ground 7 Off



1	X				2
3	4	5	6	7	

Pin NO Function

- 1 -
- 2 -
- 3 Open
- 4 Sensor (+5V)
- 5 Feedback signal
- 6 Sensor ground
- 7 Off


- Connect the auto defogging actuator connector.

- Turn the ignition switch ON.
- Check the voltage between terminals 6 and 5.
- If the measured voltage is not within specification, check the operation by replacing the existing auto defogging actuator with a new genuine part. After that, determine whether replacement of the auto defogging actuator is required or not.
- Diagnosis With GDS
- The heating, ventilation and air conditioning can be quickly diagnosed failed parts with vehicle diagnostic system (GDS). ■ The diagnostic system (GDS) provides the following information. (1) Self diagnosis : Checking the failure code (DTC) and display. (2) Current data : Checking the system input/output data state. (3) Actuation test : Checking the system operation condition. (4) Additional function : Other controlling such as he system option and zero point adjustment.
- Select the 'Car model' and the system to be checked in order to check the vehicle with the tester.
- Select the 'Current data' menu to search the current state of the input / output data. The input / output data for the sensors corresponding to the Auto Defogging Actuator can be checked.

Sensor Name	Value	Unit
<input type="checkbox"/> In-car Temperature Sensor 1	59.9	'F
<input type="checkbox"/> Ambient Air Temperature Sensor	55.4	'F
<input type="checkbox"/> Evaporator Sensor	53.6	'F
<input type="checkbox"/> Driver Photo Sensor	0.00	V
<input type="checkbox"/> Air Mix Door Potentiometer-Driver	98.4	%
<input type="checkbox"/> Direction Potentiometer-Driver	58.4	%
<input type="checkbox"/> Passenger Photo Sensor	0.00	V
<input type="checkbox"/> Air Mix Door Potentiometer-Passenger	98.4	%
<input type="checkbox"/> Intake Potentiometer	98.8	%
<input type="checkbox"/> Vehicle Speed	0	MPH
<input type="checkbox"/> Engine Coolant Temperature Sensor	50.9	'F
<input type="checkbox"/> Compressor Operating Status	OFF	-

- To perform compulsory operation on Auto Defogging Actuator input factors, select "ACTUATION TEST".


- Replacement
- Disconnect the negative (-) battery terminal.
- Remove the main crash pad assembly. (Refer to Body - "Main Crash Pad Assembly")
- Disconnect the connector (A) and then remove the auto defogging actuator (B) after loosening the mounting screws.



- To install, reverse the removal procedure.

Intake Actuator - Repair Procedures (Article 44885)

- Inspection
- Turn the ignition switch OFF.
- Disconnect the intake actuator connector.
- Verify that the intake actuator operates to the fresh position when connecting 12V to terminal 3 and grounding terminal 4. Verify that the intake actuator operates to the recirculation position when connected in reverse. Pin NO Function 1 - 2 - 3 Fresh air 4 Sensor (+5V) 5 Feedback signal 6 Sensor ground 7 Recirculated air



Pin NO Function
 1 -
 2 -
 3 Fresh air
 4 Sensor (+5V)
 5 Feedback signal
 6 Sensor ground
 7 Recirculated air

- Connect the intake actuator connector.
- Turn the ignition switch ON.
- Check the voltage between terminal 6 and 5.
- If the measured voltage is not within specification, check the operation by replacing the existing intake actuator with a new genuine part. After that, determine whether replacement of the temperature control actuator is required or not.
- Diagnosis With GDS
 - The heating, ventilation and air conditioning can be quickly diagnosed failed parts with vehicle diagnostic system (GDS). ■ The diagnostic system (GDS) provides the following information. (1) Self diagnosis : Checking the failure code (DTC) and display. (2) Current data : Checking the system input/output data state. (3) Actuation test : Checking the system operation condition. (4) Additional function : Other controlling such as he system option and zero point adjustment.
 - Select the 'Car model' and the system to be checked in order to check the vehicle with the tester.
 - Select the 'Current data' menu to search the current state of the input / output data. The input / output data for the sensors corresponding to the Intake Actuator can be checked.

Sensor Name	Value	Unit
<input type="checkbox"/> In-car Temperature Sensor 1	59.9	'F
<input type="checkbox"/> Ambient Air Temperature Sensor	55.4	'F
<input type="checkbox"/> Evaporator Sensor	53.6	'F
<input type="checkbox"/> Driver Photo Sensor	0.00	V
<input type="checkbox"/> Air Mix Door Potentiometer-Driver	98.4	%
<input type="checkbox"/> Direction Potentiometer-Driver	58.4	%
<input type="checkbox"/> Passenger Photo Sensor	0.00	V
<input type="checkbox"/> Air Mix Door Potentiometer-Passenger	98.4	%
<input type="checkbox"/> Intake Potentiometer	98.8	%
<input type="checkbox"/> Vehicle Speed	0	MPH
<input type="checkbox"/> Engine Coolant Temperature Sensor	50.9	'F
<input type="checkbox"/> Compressor Operating Status	OFF	-

- To perform compulsory operation on Intake Actuator input factors, select "ACTUATION TEST".

Actuation Test

Test Items


- Driver Air Mix Door-0%
- Driver Air Mix Door-50%
- Driver Air Mix Door-100%
- Passenger Air Mix Door-0%
- Passenger Air Mix Door-50%
- Passenger Air Mix Door-100%
- Driver Mode Door-Vent
- Driver Mode Door-Floor
- Driver Mode Door-Defrost
- Air Inlet Mode Selection-Fresh
- Air Inlet Mode Selection-Recirculation

Configuration:

- Duration: Until Stop Button
- Conditions: IG. ON
- Result: Success

Start **Stop**


- Replacement
 - Disconnect the negative (-) battery terminal.
 - Remove the main crash pad assembly. (Refer to Body - "Main Crash Pad Assembly")
 - Disconnect the connector (A) and then remove the intake actuator (B) after loosening the mounting screws.



- To install, reverse the removal procedure.

Mode Control Actuator - Repair Procedures (Article 44869)

- Inspection
- Turn the ignition switch OFF.
- Disconnect the mode control actuator connector.
- Verify that the mode control actuator operates to the defrost mode when connecting 12V to terminal 3 and grounding terminal 4. Verify that the mode control actuator operates to the vent mode when connected in reverse. Pin NO Function 1 - 2 - 3 Vent mode 4 Sensor (+5V) 5 Feedback signal 6 Sensor ground 7 Defrost mode



Pin NO Function

- 1 -
- 2 -
- 3 Vent mode
- 4 Sensor (+5V)
- 5 Feedback signal
- 6 Sensor ground
- 7 Defrost mode


- Connect the mode control actuator connector.

- Turn the ignition switch ON.
- Check the voltage between terminal 6 and 5.
- If the measured voltage is not within specification, check the operation by replacing the existing mode control actuator with a new genuine part. After that, determine whether replacement of the temperature control actuator is required or not.
- Diagnosis With GDS
- The heating, ventilation and air conditioning can be quickly diagnosed failed parts with vehicle diagnostic system (GDS). ■ The diagnostic system (GDS) provides the following information. (1) Self diagnosis : Checking the failure code (DTC) and display. (2) Current data : Checking the system input/output data state. (3) Actuation test : Checking the system operation condition. (4) Additional function : Other controlling such as he system option and zero point adjustment.
- Select the 'Car model' and the system to be checked in order to check the vehicle with the tester.
- Select the 'Current data' menu to search the current state of the input / output data. The input / output data for the sensors corresponding to the Mode Control Actuator can be checked.

Sensor Name	Value	Unit
<input type="checkbox"/> In-car Temperature Sensor 1	59.9	'F
<input type="checkbox"/> Ambient Air Temperature Sensor	55.4	'F
<input type="checkbox"/> Evaporator Sensor	53.6	'F
<input type="checkbox"/> Driver Photo Sensor	0.00	V
<input type="checkbox"/> Air Mix Door Potentiometer-Driver	98.4	%
<input type="checkbox"/> Direction Potentiometer-Driver	58.4	%
<input type="checkbox"/> Passenger Photo Sensor	0.00	V
<input type="checkbox"/> Air Mix Door Potentiometer-Passenger	98.4	%
<input type="checkbox"/> Intake Potentiometer	98.8	%
<input type="checkbox"/> Vehicle Speed	0	MPH
<input type="checkbox"/> Engine Coolant Temperature Sensor	50.9	'F
<input type="checkbox"/> Compressor Operating Status	OFF	-

- To perform compulsory operation on Mode Control Actuator input factors, select "ACTUATION TEST".


- Replacement
- Disconnect the negative (-) battery terminal.
- Remove the main crash pad assembly. (Refer to Body - "Main Crash Pad Assembly")
- Disconnect the connector (A) and then remove the mode control actuator (B) after loosening the mounting screws.



- To install, reverse the removal procedure.

Temperature Control Actuator - Repair Procedures (Article 44864)

- Inspection
- Turn the ignition switch OFF.
- Disconnect the temperature control actuator connector.
- Verify that the temperature control actuator operates to the cool position when connecting 12V to terminal 3 and grounding terminal 7. Verify that the temperature control actuator operates to the warm position when connected in reverse. Pin NO Function 1 - 2 - 3 Cool position 4 Sensor (+5V) 5 Feedback signal 6 Sensor ground 7 Warm position




- Pin NO Function
- 1 -
 - 2 -
 - 3 Cool position
 - 4 Sensor (+5V)
 - 5 Feedback signal
 - 6 Sensor ground
 - 7 Warm position

- Connect the temperature control actuator connector.
- Turn the ignition switch ON.
- Check the voltage between terminal 5 and 6.
- If the measured voltage is not within specification, check the operation by replacing the existing temperature control actuator with a new genuine part. After that, determine whether replacement of the temperature control actuator is required or not.
- Diagnosis With GDS
 - The heating, ventilation and air conditioning can be quickly diagnosed failed parts with vehicle diagnostic system (GDS). ■ The diagnostic system (GDS) provides the following information. (1) Self diagnosis : Checking the failure code (DTC) and display. (2) Current data : Checking the system input/output data state. (3) Actuation test : Checking the system operation condition. (4) Additional function : Other controlling such as he system option and zero point adjustment.
 - Select the 'Car model' and the system to be checked in order to check the vehicle with the tester.
 - Select the 'Current data' menu to search the current state of the input / output data. The input / output data for the sensors corresponding to the Temperature Control Actuator can be checked.


Sensor Name	Value	Unit
<input type="checkbox"/> In-car Temperature Sensor 1	59.9	'F
<input type="checkbox"/> Ambient Air Temperature Sensor	55.4	'F
<input type="checkbox"/> Evaporator Sensor	53.6	'F
<input type="checkbox"/> Driver Photo Sensor	0.00	V
<input type="checkbox"/> Air Mix Door Potentiometer-Driver	98.4	%
<input type="checkbox"/> Direction Potentiometer-Driver	58.4	%
<input type="checkbox"/> Passenger Photo Sensor	0.00	V
<input type="checkbox"/> Air Mix Door Potentiometer-Passenger	98.4	%
<input type="checkbox"/> Intake Potentiometer	98.8	%
<input type="checkbox"/> Vehicle Speed	0	MPH
<input type="checkbox"/> Engine Coolant Temperature Sensor	50.9	'F
<input type="checkbox"/> Compressor Operating Status	OFF	-

- To perform compulsory operation on Temperature Control Actuator input factors, select "ACTUATION TEST".

- Replacement
[Driver's side]
- Disconnect the negative (-) battery terminal.
- Remove the crash pad lower panel. (Refer to Body - "Crash Pad Lower Panel")
- Remove the driver's side shower duct (A) after loosening the screw.



- Disconnect the connector (A) and then remove the driver's side temperature control actuator (B) after loosening the mounting screws.




- To install, reverse the removal procedure.


[Passenger's side]

- Remove the glove box upper cover assembly. (Refer to Body - "Glove Box Upper Cover Assembly")

- Remove the passenger's side shower duct (A) after loosening the screw.



- Disconnect the connector (A) and then remove the passenger's side temperature control actuator (B) after loosening the mounting screws.



Auto Defogging Actuator - Specifications (Article 44872)

- Specifications

Door position Voltage (V) Error detecting

Max. cooling 0.3 ± 0.15 Low voltage : 0.1V or less

Max. heating 4.7 ± 0.15 High voltage : 4.9V or more

Intake Actuator - Specifications (Article 44884)

- Specifications

Door position Voltage (V) Error detecting

Max. cooling 0.3 ± 0.15 Low voltage : 0.1V or less

Max. heating 4.7 ± 0.15 High voltage : 4.9V or more

Mode Control Actuator - Specifications (Article 44868)

- Specifications

Door position Voltage (V) Error detecting

Max. cooling 0.3 ± 0.15 Low voltage : 0.1V or less
Max. heating 4.7 ± 0.15 High voltage : 4.9V or more

Temperature Control Actuator - Specifications (Article 44862)

- Specifications

Door Position Voltage (V) Error Detecting

Max. cooling 0.3 ± 0.15 Low voltage : 0.1V or less High voltage : 4.9V or more

Max. heating 4.7 ± 0.15