

# Component Procedures: Oxygen Sensor

## Table of Contents

1. Parts and Labor (itype\_189)
2. Heated Oxygen Sensor (HO2S) - Description and Operation (Article 44126)
3. Heated Oxygen Sensor (HO2S) - Schematic Diagrams (Article 44128)
4. Heated Oxygen Sensor (HO2S) - Repair Procedures (Article 44130)
5. Heated Oxygen Sensor (HO2S) - Specifications (Article 44127)

# Component Procedures: Oxygen Sensor

## Parts and Labor (itype\_189)

### Parts


Qualifier	Part #	Name	Price	Note
Powertrain Control > Oxygen ?	392102ECC0	Lower	207.94	
Powertrain Control > Oxygen ?	392102E101	Upper	235.58	

### Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Powertrain Control > Oxygen Sensor, R&R > Fro?	B	0.5	0.0
Remove & Replace	Powertrain Control > Oxygen Sensor, R&R > Rear	B	0.6	0.0


## Heated Oxygen Sensor (HO2S) - Description and Operation (Article 44126)

- Description



## Heated Oxygen Sensor (HO2S) - Schematic Diagrams (Article 44128)

- Circuit Diagram





## Heated Oxygen Sensor (HO2S) - Repair Procedures (Article 44130)



- Inspection
  - Turn the ignition switch OFF.
  - Disconnect the HO2S connector.
  - Measure resistance between the HO2S terminals 2 and 5 [B1/S1]. Measure resistance between the HO2S terminals 3 and 4 [B1/S2].
  - Check that the resistance is within the specification. Specification : Refer to "Specification"
  - Removal
  - Turn the ignition switch OFF and disconnect the battery negative (-) cable.
  - Disconnect the connector (A), and then remove the sensor (B). Note that the SST (Part No.: 09392-2H100) is useful when removing the heated oxygen sensor . [Bank 1 / Sensor 1] [Bank 1 / Sensor 2]
- Note that the SST (Part No.: 09392-2H100) is useful when removing the heated oxygen sensor .

# NOTICE

- Note that the SST (Part No.: 09392-2H100) is useful when removing the heated oxygen sensor . [Bank 1 / Sensor 1]



[Bank 1 / Sensor 2]



- Installation

Install the component with the specified torques. Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.



- Install the component with the specified torques.

- Note that internal damage may occur when the component is dropped. In this case, use it after inspecting.

DON'T use a cleaner, spray, or grease to sensing element and connector of the sensor because oil component in them may malfunction the sensor performance. Sensor and its wiring may be damaged in case of contacting with the exhaust system (Exhaust Manifold, Catalytic Converter , and so on).

- DON'T use a cleaner, spray, or grease to sensing element and connector of the sensor because oil component in them may malfunction the sensor performance.
- Sensor and its wiring may be damaged in case of contacting with the exhaust system (Exhaust Manifold, Catalytic Converter , and so on).
- Installation is reverse of removal. Heated oxygen sensor installation : 39.2 - 49.1 N.m (4.0 - 5.0 kgf.m, 28.9 - 36.2 lb-ft)

### **Heated Oxygen Sensor (HO2S) - Specifications (Article 44127)**

- Specification
- HO2S [Bank 1/Sensor 1] (Linear type)
- Item Specification
- Heater Resistance ( $\Omega$ ) 2.4 - 4.0 [20°C (68°F)]
- HO2S [Bank 1/Sensor 2] (Binary type)
- A/F Ratio ( $\lambda$ ) Output Voltage (V)
- RICH 0.6 - 1.0
- LEAN 0 - 0.4
- Heater Resistance ( $\Omega$ ) Approx. 9.0 [20°C (68°F)]