

Component Procedures: Hose/Line HVAC

Table of Contents

1. Parts and Labor (itype_189)
2. Refrigerant line - Components and Components Location (Article 44844)
3. Refrigerant Line - Repair Procedures (Article 44845)

Component Procedures: Hose/Line HVAC

Parts and Labor (itype_189)

Parts


Qualifier	Part #	Name	Price	Note
Air Conditioner > Discharge ?	97762M6450	Korea Built	116.53	
Air Conditioner > Discharge ?	97762F3500	Us Built	126.77	
Air Conditioner > Suction Ho?	97775M6450	Korea Built	642.52	
Air Conditioner > Suction Ho?	97775F3500	Us Built	754.65	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Air Conditioner > Discharge Hose, R&R	B	1.4	0.0
Remove & Replace	Air Conditioner > Liquid & Suction Hose Assem?	B	1.9	0.0

Refrigerant line - Components and Components Location (Article 44844)


- Components Location




1. Refrigerant Line Assembly

Refrigerant Line - Repair Procedures (Article 44845)


- Replacement
- If the compressor is marginally operable, run the engine at idle speed, and let the air conditioning work for a few minutes, then shut the engine off.
- Disconnect the negative (-) battery terminal.
- Recover the refrigerant with a recovery / charging station.
- Remove the engine cover (A).




- Remove the bolts and the expansion valve (A) from the evaporator core . Tightening torque : 8.8 - 13.7 N.m (0.9 - 1.4 kgf.m, 6.5 - 10.1 lb-ft)



- Remove the 2 nuts, and then disconnect the discharge line (A) and liquid line (B) from the condenser .
Tightening torque : 8.8 - 13.7 N.m (0.9 - 1.4 kgf.m, 6.5 - 10.1 lb-ft)



- Disconnect the A/C pressure transducer connector (A).



- Remove the engine room under cover. (Refer to Engine Mechanical System - "Engine Room Under Cover")
- Remove the bolts, then disconnect the suction line (A) and discharge line (B) from the compressor.
Tightening torque : 21.6 - 32.4 N.m (2.2 - 3.3 kgf.m, 15.9 - 23.9 lb-ft) Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.
Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.




Information

- Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.
- Loosen the bracket mounting bolt (B) from suction & liquid assembly (A). Tightening torque : 7.8 - 11.8 N.m (

0.8 - 1.2 kgf.m, 5.8 - 8.7 lb-ft)

- Remove the refrigerant line assembly (A) to the upper of engine room.



- To install, reverse the removal procedure. Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination. Tighten the bolt or nut joint to the specified torque. Using a gas leak detector, check for refrigerant leakage. Evacuate air in the refrigeration system and charge system with refrigerant. Capacity : 500 ± 25 g (17.6 ± 0.88 oz.)

Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination. Tighten the bolt or nut joint to the specified torque. Using a gas leak detector, check for refrigerant leakage.

Evacuate air in the refrigeration system and charge system with refrigerant. Capacity : 500 ± 25 g (17.6 ± 0.88 oz.)



- Tighten the bolt or nut joint to the specified torque.

- Using a gas leak detector, check for refrigerant leakage.

- Evacuate air in the refrigeration system and charge system with refrigerant. Capacity : 500 ± 25 g (17.6 ± 0.88 oz.)