

Component Procedures: Gear Sensor/Switch

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Gear Sensor/Switch

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
NP231 Non-Synchro, NV231 > I?	J8134473	10 - Switch	0.00	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Indicator Lamp Switch	B	0.4	0.3