

# Component Procedures: Odometer

## Table of Contents

1. Procedures (itype\_376)

# Component Procedures: Odometer

## Procedures (itype\_376)

Odometer

Reset Knob Boot

WARNING: ON VEHICLES EQUIPPED WITH AIRBAGS, REFER TO AIRBAG AND SEAT BELTS/AIR BAGS BEFORE ATTEMPTING ANY STEERING WHEEL, STEERING COLUMN, OR

INSTRUMENT PANEL

COMPONENT DIAGNOSIS OR SERVICE. FAILURE TO TAKE THE PROPER PRECAUTIONS COULD RESULT IN ACCIDENTAL AIR-BAG DEPLOYMENT AND POSSIBLE PERSONAL INJURY

.

### REMOVAL

1. Disconnect and isolate the battery negative cable.

2. Remove the instrument cluster

from the instrument panel. Refer to instrument

Cluster

in the Service and Repair for the procedures.

3. Remove the cluster lens from the cluster housing

. Refer to instrument Cluster Components - Cluster Lens in the Service and Repair for the procedures.

4. Remove the odometer reset knob boot by pulling it out of the cluster lens.

### INSTALLATION

1. Position the odometer reset knob to the mounting hole from the back of the cluster lens.

2. Pull the odometer reset knob into the mounting hole from the face of the cluster lens.

3. Install the cluster lens onto the cluster housing. Refer to instrument Cluster Components - Cluster Lens in the Service and Repair for the procedures.

4. Install the instrument cluster onto the instrument panel. Refer to instrument Cluster in the Service and Repair for the procedures.

5. Reconnect the battery negative cable.