


Component Procedures: Brake Fluid Pressure Sensor/Switch

Table of Contents

1. Connector Views (itype_47)

Component Procedures: Brake Fluid Pressure Sensor/Switch

Connector Views (itype_47)



BRAKE WARNING INDICATOR SWITCH - BLACK 2 WAY

CAV	CIRCUIT	FUNCTION
1	G9 20GY/BK	RED BRAKE WARNING INDICATOR DRIVER
2	G99 20GY/WT	RED BRAKE WARNING INDICATOR DRIVER