

Component Procedures: Trunk Lamp

Table of Contents

1. Procedures (itype_376)

Component Procedures: Trunk Lamp

Procedures (itype_376)

REMOVAL

Vehicles equipped with a hardtop have a dome lamp located above the rear window lift glass.

1. Remove the dome

/

cargo lamp

lens by squeezing it at the top and bottom. This will separate the lens retaining tabs from the lamp housing shoulders.

2. Remove the lens from the lamp housing.
3. Remove the bulb.
4. Remove the screws that attach the lamp to the hardtop.
5. Separate the lamp from the hardtop.
6. Disconnect the lamp wire connector.

INSTALLATION

1. Connect the lamp wire connector.
2. Position the lamp in the hardtop.
3. Install the screws that attach the lamp to the hardtop.
4. Install the bulb.
5. Position the lens on the lamp housing and press into place.