

# Component Procedures: Fuel Filter

## Table of Contents

1. Parts and Labor (itype\_189)
2. Components (itype\_392)
3. Components (itype\_32)
4. Procedures (itype\_376)

# Component Procedures: Fuel Filter

## Parts and Labor (itype\_189)



### Parts

Qualifier	Part #	Name	Price	Note
Fuel Filter	4798301	Fuel Filter	0.00	



### Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Fuel Filter, R&R	C	1.6	1.0


## Components (itype\_392)




## Components (itype\_32)



Procedures (itype\_376)



80a58b62



80a58b63

