

Component Procedures: Timing Cover

Table of Contents

1. Parts and Labor (itype_189)
2. Removal and Installation (Article 2079425)

Component Procedures: Timing Cover

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Front Cover	53020222	17 - Timing Cover	0.00	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Front Cover	B	2.7	2.0
Replace	Front Cover > NOTE > With AC, Add	B	0.9	0.6
Replace	Front Cover > NOTE > With PS, Add	B	0.2	0.2

Removal and Installation (Article 2079425)

