

Component Procedures: Parking Pawl

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Parking Pawl

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
30RH/31RH/32RH > Spring > Go?	2466909	1 - Spring	0.00	
30RH/31RH/32RH > Parking Pawl?	4471415	2 - Parking Brake Sprag	0.00	
30RH/31RH/32RH > Plug > Gove?	2538042	3 - Plug	0.00	
30RH/31RH/32RH > Snap Ring >?	2538034	4 - Snap Ring	0.00	
30RH/31RH/32RH > Parking Pawl?	2466892	5 - Shaft	0.00	
30RH/31RH/32RH > Parking Pawl?	2466906	6 - Rod Assy	0.00	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	30RH/31RH/32RH > Parking Pawl	B	2.5	1.8
Replace	30RH/31RH/32RH > Parking Pawl Actuator Rod	B	1.3	0.9