

# Component Procedures: Differential Case

## Table of Contents

1. Parts and Labor (itype\_189)

# Component Procedures: Differential Case

## Parts and Labor (itype\_189)

### Parts

Qualifier	Part #	Name	Price	Note
Front Axle > Differential Ca?	5252582	12 - Differential Case	522.00	Order By Description.
Front Axle > Differential Ca?	5252590	12 - Differential Case	0.00	Order By Description.
Rear Axle > Differential Cas?	52098776	7 - Differential Case	0.00	Order By Description.
Rear Axle > Differential Cas?	52098778	7 - Differential Case	542.00	Order By Description.
Rear Axle > Differential Cas?	4740833	7 - Differential Case	0.00	Order By Description.
Rear Axle > Differential Cas?	4740834	7 - Differential Case	0.00	Order By Description.
Rear Axle > Differential Cas?	5252512	7 - Differential Case	0.00	Order By Description.
Rear Axle > Differential Cas?	83505431	7 - Differential Case	0.00	Order By Description.

### Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Front Axle > Complete Assembly With Transfer ?	B	5.5	4.4
Replace	Front Axle > Complete Assembly With Transfer ?	B	1.2	1.1
Replace	Rear Axle > Complete Assembly With Transfer O?	B	3.5	2.3
Replace	Rear Axle > Complete Assembly With Transfer O?	B	3.2	1.9
Replace	Rear Axle > Complete Assembly With Transfer O?	B	3.8	2.5
Replace	Rear Axle > Complete Assembly With Transfer O?	B	3.5	2.1
Replace	Rear Axle > Complete Assembly Without Transfe?	B	2.7	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	0.5	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	0.2	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	0.5	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	0.2	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	0.2	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	1.0	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	0.4	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	3.0	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	0.5	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	0.2	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	0.5	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	0.2	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	0.2	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	1.0	0.0
Replace	Rear Axle > Complete Assembly Without Transfe?	B	0.4	0.0