

Component Procedures: Fluid - M/T

Table of Contents

1. Parts and Labor (itype_189)
2. Vehicle Damage Warnings (itype_16)
3. Capacities (itype_30)
4. Fluid Types (itype_31)
5. Fluid Types and Capacities (itype_436)

Component Procedures: Fluid - M/T

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Trans Fluid, Change	C	0.5	0.0

Vehicle Damage Warnings (itype_16)

DO NOT
over fill transmission beyond normal fluid level markings. Fluid foaming and transmission damage may occur.

Capacities (itype_30)

Transmission Fluid

AX5

4WD 3.3L (7.0 Pints)

2WD 3.5L (7.4 Pints)

AX15

4WD 3.1L (6.5 Pints)

2WD 3.1L (6.5 Pints)

Fluid Types (itype_31)

Transmission Fluid

Grade API GL-3 or equivalent

Viscosity SAE 75W-90

Fluid Types and Capacities (itype_436)

Fluid Types

Capacities