

Component Procedures: Neutral Safety Switch

Table of Contents

1. Parts and Labor (itype_189)
2. Connector Views (itype_47)
3. Components (itype_32)

Component Procedures: Neutral Safety Switch

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Back-Up Switch	83500629	Back-up Switch	0.00	Order By Description.
Neutral Safety Switch	3747361	Neutral Safety Switch	34.00	Order By Description.

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Neutral Safety Switch, R&R	B	0.5	0.3

Connector Views (itype_47)



**PARK/NEUTRAL
POSITION SWITCH
(A/T)**

PARK/NEUTRAL POSITION SWITCH (A/T) - 3 WAY

CAV	CIRCUIT	FUNCTION
1	F20 18VT/WT	FUSED IGNITION SWITCH OUTPUT (RUN)
2	T41 20BR/LB	PARK/NEUTRAL POSITION SWITCH SENSE
3	L1 18VT/BK	BACK-UP LAMP FEED

Components (itype_32)

