

Component Procedures: Seals and Gaskets

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Seals and Gaskets

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
30RH/31RH/32RH > Overhaul Ga?	NO LISTING	Overhaul Gasket Set	0.00	
30RH/31RH/32RH > Overhaul Ga?	4883957AB	Overhaul Gasket Set	111.00	
30RH/31RH/32RH > Dipstick Tu?	52118629	4 - Oil Filler Tube Se?	2.60	
30RH/31RH/32RH > Manual Shaf?	4505098	6 - Seal	13.75	
30RH/31RH/32RH > Oil Pan Gas?	4295875	11 - Automatic Transmi?	4.70	
30RH/31RH/32RH > Extension H?	2466954	12 - Gasket	0.00	
30RH/31RH/32RH > Extension H?	4638941	18 - Oil Seal	15.25	
30RH/31RH/32RH > Oil Pump Ov?	4713108AB	Oil Pump Gasket & Seal?	0.00	
30RH/31RH/32RH > Front Pump ?	4412475	1 - Torque Converter S?	35.95	
30RH/31RH/32RH > Valve Body ?	4713105	Valve Body Gasket & Se?	39.75	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	30RH/31RH/32RH > Adapter Gasket	B	2.7	1.8
Replace	30RH/31RH/32RH > Dipstick Tube Seal	C	0.4	0.3
Replace	30RH/31RH/32RH > Front Pump Seal	B	4.9	3.3
Replace	30RH/31RH/32RH > Manual Shaft Seal	C	0.7	0.4
Replace	30RH/31RH/32RH > Oil Pan Gasket	B	0.8	0.5
Replace	30RH/31RH/32RH > Oil Pan Gasket > NOTE > To A?	B	0.2	0.1
Replace	30RH/31RH/32RH > Oil Pan Gasket > NOTE > To A?	B	0.2	0.1
Replace	30RH/31RH/32RH > Oil Pan Gasket > NOTE > To A?	B	0.2	0.1
Replace	30RH/31RH/32RH > Oil Pan Gasket > NOTE > To R?	B	0.1	0.1
Replace	30RH/31RH/32RH > Throttle Shaft Seal	C	0.5	0.3