

Component Procedures: Backup Lamp Switch

Table of Contents

1. Parts and Labor (itype_189)
2. Components (itype_32)
3. Mechanical (including Torque) (itype_28)

Component Procedures: Backup Lamp Switch

Parts and Labor (itype_189)


Parts

Qualifier	Part #	Name	Price	Note
Back-Up Switch	83500629	Back-up Switch	0.00	Order By Description.

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Back-up Switch, R&R	B	0.5	0.3

Components (itype_32)



Mechanical (including Torque) (itype_28)

Switch, Back-up Lamp 32.5 ft.lb