

# **Component Procedures: Ambient Temperature Sensor / Switch HVAC**

## **Table of Contents**

1. Parts and Labor (itype\_189)
2. HVAC Control System (Article 1439339)
3. Removal and Replacement (itype\_401)
4. All Technical Service Bulletins (itype\_100)
5. Customer Interest Bulletins (itype\_109)
6. Component Tests and General Diagnostics (itype\_383)

# Component Procedures: Ambient Temperature Sensor / Switch HVAC

## Parts and Labor (itype\_189)

### Parts


Qualifier	Part #	Name	Price	Note
Ambient Temp Sensor	G51861764	Ambient Temp Sensor	65.62	

## HVAC Control System (Article 1439339)

### Non Standards


- Full-Auto Air Conditioner (1439340)
- Manual Air Conditioner (1439341)

## Removal and Replacement (itype\_401)



e3u740zw6105

1	Ambient temperature sensor connector
2	Ambient temperature sensor



am3uuw0000063

## All Technical Service Bulletins (itype\_100)

### Tsbs


- Instruments - Ambient Temperature Display Incorrectly (0901009, 2009/03/03)

## Customer Interest Bulletins (itype\_109)

### Tsbs

- Instruments - Ambient Temperature Display Incorrectly (0901009, 2009/03/03)

# Component Tests and General Diagnostics (itype\_383)



am3zzw0000076