

Component Procedures: Fog/Driving Lamp Switch





Table of Contents

1. Component Tests and General Diagnostics (itype_383)


Component Procedures: Fog/Driving Lamp Switch

Component Tests and General Diagnostics (itype_383)

 : Continuity

Switch position		Terminal	
Light	Front fog light switch	E	H
OFF	OFF		
	ON		
TNS	ON		
Head light	ON		
Auto	ON		

C3U0918W133



c3u0918w132