

Component Procedures: Pressure Regulating Solenoid

Table of Contents

1. [FS5A-EI] Automatic Transmission/Transaxle (Article 1359642)
2. [FN4A-EI] Automatic Transmission/Transaxle (Article 1359648)
3. [FN4A-EI] Automatic Transmission/Transaxle (Article 1359966)
4. [FS5A-EI] Automatic Transmission/Transaxle (Article 1359968)

Component Procedures: Pressure Regulating Solenoid

[FS5A-EI] Automatic Transmission/Transaxle (Article 1359642)

Non Standards

- Solenoid Valve Removal/Installation (Primary Control Valve Body) (1359643)
- Solenoid Valve Removal/Installation (Secondary Control Valve Body) (1359646)

[FN4A-EI] Automatic Transmission/Transaxle (Article 1359648)

Non Standards

- Solenoid Valve Removal/Installation (1359649)

[FN4A-EI] Automatic Transmission/Transaxle (Article 1359966)

Non Standards

- Solenoid Valve Inspection (1359967)

[FS5A-EI] Automatic Transmission/Transaxle (Article 1359968)

Non Standards

- Solenoid Valve Inspection (Secondary Control Valve Body) (1359969)
- Solenoid Valve Inspection (Primary Control Valve Body) (1359970)