

Component Procedures: Wheel Speed Sensor

Table of Contents

1. Parts and Labor (itype_189)
2. Antilock Brake System (Article 1463982)
3. Dynamic Stability Control (Article 1463984)
4. Front (Article 1362156)
5. Rear (Article 1362157)
6. Front (Article 1361607)
7. Rear (Article 1361989)

Component Procedures: Wheel Speed Sensor

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Front Speed Sensor	BP4K43701A	Front Speed Sensor	97.97	
Rear Speed Sensor	BP4K43711B	Rear Speed Sensor	49.16	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Front Speed Sensor > One Side	B	0.5	0.3
Replace	Front Speed Sensor > Both Sides	B	0.7	0.4
Replace	Rear Speed Sensor > One Side	B	0.7	0.4
Replace	Rear Speed Sensor > Both Sides	B	0.8	0.5

Antilock Brake System (Article 1463982)

Non Standards

- ABS Location Index (1463983)

Dynamic Stability Control (Article 1463984)

Non Standards

- DSC Location Index (1463992)

Front (Article 1362156)

Non Standards

- Antilock Brake System (1362181)
- Dynamic Stability Control (1362183)

Rear (Article 1362157)

Non Standards

- Antilock Brake System (1362185)
- Dynamic Stability Control (1362187)

Front (Article 1361607)

Non Standards

- Antilock Brake System (1362032)
- Dynamic Stability Control (1362034)

Rear (Article 1361989)

Non Standards

- Antilock Brake System (1362036)
- Dynamic Stability Control (1362038)