

# Component Procedures: Power Locks

## Table of Contents


1. Electrical (OE) (itype\_21)
2. Door Locks (Article 14909)
3. Components (itype\_32)

# Component Procedures: Power Locks

## Electrical (OE) (itype\_21)


POWER DOOR LOCK SYSTEM

0914-1a




POWER OUTER MIRROR

0912-3




POWER DOOR LOCK SYSTEM



0914-1b



POWER DOOR LOCK SYSTEM

0914-1b





## Door Locks (Article 14909)


Door Locks

Page 1 of 1

## Components (itype\_32)

SECURITY AND LOCKS LOCATION INDEX


0001-0000010



1	Inner handle	4	Rear door latch and lock actuator
2	Door lock switch	5	Front outer handle
3	Front door latch and lock actuator	6	Front door key cylinder
		7	Rear outer handle
		8	Door lock striker

9	Trunk lid key cylinder
10	Trunk lid latch
11	Trunk lid lock striker

12	Liftgate latch and lock actuator
13	Liftgate outer handle
14	Liftgate lid lock striker



1	Instrument cluster	7	Trunk lid opener lever
2	Coil antenna	8	Fuel-filler lid opener lever
3	PJB	9	Fuel-filler lid opener cable
4	Hood release lever	10	Trunk lid opener cable
5	Hood latch	11	Fuel-filler lid opener
6	Hood cable	12	Keyless control module
		13	Transmitter