

Component Procedures: Starter Solenoid

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Starter Solenoid

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Solenoid	L32718X10	2 - Solenoid	140.39	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Solenoid, R&R	B	1.1	0.8