

# **Component Procedures: Firing Order**


## **Table of Contents**

1. Mechanical (including Torque) (itype\_28)

## Component Procedures: Firing Order

Mechanical (including Torque) (itype\_28)

**Firing Order : 1-3-4-2**



**Front of Vehicle**