

Component Procedures: Band Control Solenoid Valve

Table of Contents

1. [FS5A-EI] Automatic Transmission/Transaxle (Article 1422559)
2. [FN4A-EI] Automatic Transmission/Transaxle (Article 1422562)
3. [FN4A-EI] Automatic Transmission/Transaxle (Article 1422512)
4. [FS5A-EI] Automatic Transmission/Transaxle (Article 1422514)

Component Procedures: Band Control Solenoid Valve

[FS5A-EI] Automatic Transmission/Transaxle (Article 1422559)

Non Standards

- Solenoid Valve Removal/Installation (Primary Control Valve Body) (1422560)
- Solenoid Valve Removal/Installation (Secondary Control Valve Body) (1422561)

[FN4A-EI] Automatic Transmission/Transaxle (Article 1422562)

Non Standards

- Solenoid Valve Removal/Installation (1422563)

[FN4A-EI] Automatic Transmission/Transaxle (Article 1422512)

Non Standards

- Solenoid Valve Inspection (1422513)

[FS5A-EI] Automatic Transmission/Transaxle (Article 1422514)

Non Standards

- Solenoid Valve Inspection (Secondary Control Valve Body) (1422515)
- Solenoid Valve Inspection (Primary Control Valve Body) (1422516)