

# **Component Procedures: Global Positioning System Antenna**


## **Table of Contents**

1. Removal and Replacement (itype\_401)

# Component Procedures: Global Positioning System Antenna

## Removal and Replacement (itype\_401)

1	Screw
2	GPS antenna



c3u0920w108