

Component Procedures: Air Filter Element

Table of Contents

1. Parts and Labor (itype_189)
2. Component Tests and General Diagnostics (itype_383)

Component Procedures: Air Filter Element

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Air Filter	LF5013Z409U	Air Filter	21.58	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Air Filter, R&R	C	0.3	0.2

Component Tests and General Diagnostics (itype_383)

AIR CLEANER ELEMENT

INSPECTION[LF, L3]

1. Remove the air cleaner element.
2. Inspect the following items:
 - If there is any abnormality, clean or replace the air cleaner element.
 - Has the replacement interval come?
 - Is the air cleaner element soiled, damaged, or bent?
 - Are the air cleaner case and the air cleaner element correctly sealed?
 - Is the correct air cleaner element installed?