

Component Procedures: Door Lock Cylinder Switch

Table of Contents

1. Component Tests and General Diagnostics (itype_383)


Component Procedures: Door Lock Cylinder Switch

Component Tests and General Diagnostics (itype_383)

○—○ : Continuity

Key cylinder position	Terminal		
	B	LH: A RH: I	F
Lock (Set)		○—○	
Unlock (Reset)	○—○		
Neutral			

B3E0914W016



C3U0914W008