

Component Procedures: Parking Brake Warning Switch

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Parking Brake Warning Switch

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Park Brake Warning Switch, R&R	B	0.7	0.5