

# **Component Procedures: Rear Door Window Regulator**

## **Table of Contents**

1. Parts and Labor (itype\_189)
2. Rear Power Window Regulator Removal/Installation (Article 1367581)
3. Rear Manual Window Regulator Removal/Installation (Article 1368441)

# Component Procedures: Rear Door Window Regulator

## Parts and Labor (itype\_189)


### Parts

Qualifier	Part #	Name	Price	Note
Window Regulator > 4 Door > ?	BP4L72560D	Window Regulator	99.74	
Window Regulator > 4 Door > ?	BP4K72590E	Window Regulator	74.88	
Window Regulator > 4 Door > ?	BP4L73560D	Window Regulator	98.59	
Window Regulator > 4 Door > ?	BP4K73590E	Window Regulator	104.16	
Window Regulator > 5 Door > ?	BP4K72590E	Window Regulator	74.88	
Window Regulator > 5 Door > ?	BP4K73590E	Window Regulator	104.16	


### Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	One Side	B	0.7	0.5


## Rear Power Window Regulator Removal/Installation (Article 1367581)



B3E0912W220




am3uuw0000136




CHU0912WT33

**Rear Manual Window Regulator Removal/Installation (Article 1368441)**



B3E0912W117



B3E0912W203