

Component Procedures: Front Door Window Regulator

Table of Contents

1. Parts and Labor (itype_189)
2. Front Power Window Regulator Removal/Installation (Article 1367570)
3. Front Manual Window Regulator Removal/Installation (Article 1369303)

Component Procedures: Front Door Window Regulator

Parts and Labor (itype_189)


Parts

Qualifier	Part #	Name	Price	Note
Window Regulator > Right > W?	BP4L58560A	Window Regulator	87.68	
Window Regulator > Right > W?	BP4K58590A	Window Regulator	91.63	
Window Regulator > Left > Wi?	BP4L59560A	Window Regulator	111.54	
Window Regulator > Left > Wi?	BP4K59590A	Window Regulator	120.30	


Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	One Side	B	0.7	0.5


Front Power Window Regulator Removal/Installation (Article 1367570)



B3E0912W112




am3uuw0000136




B3E0912W103

Front Manual Window Regulator Removal/Installation (Article 1369303)



B3E0912W118



MANUAL WINDOW REGULATOR

B3E0912W205