


Component Procedures: Windshield Washer Spray Nozzle

Table of Contents

1. Front Washer Nozzle Adjustment (Article 1468521)
2. Rear Washer Nozzle Adjustment (Article 1463781)
3. Windshield Washer Nozzle Cleaning (Article 1464172)
4. Windshield Washer Nozzle (Article 1463776)
5. Rear Washer Nozzle (Article 1463777)

Component Procedures: Windshield Washer Spray Nozzle

Front Washer Nozzle Adjustment (Article 1468521)




B3E0919W137

Rear Washer Nozzle Adjustment (Article 1463781)


REAR WASHER NOZZLE ADJUSTMENT

1. Insert a needle or an equivalent tool into the spray hole of the rear washer nozzle and adjust the nozzle direction as shown.

id091900802300




Windshield Washer Nozzle Cleaning (Article 1464172)




am3uuw0000012

Windshield Washer Nozzle (Article 1463776)



am3uuw0000006

Rear Washer Nozzle (Article 1463777)



am3uuw000007