

# **Component Procedures: Suspension Spring ( Coil / Leaf )**

## **Table of Contents**

1. Parts and Labor (itype\_189)
2. Front Suspension (Article 1383520)
3. Front Suspension (Article 1383489)

# Component Procedures: Suspension Spring ( Coil / Leaf )

## Parts and Labor (itype\_189)

### Parts

Qualifier	Part #	Name	Price	Note
Front Suspension > Coil Sprin?	BN8H34011C	4 - Coil Spring	120.96	
Rear Suspension > Coil Spring	BP4K28011B	5 - Coil Spring	64.95	

### Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Front Suspension > One Side	B	1.5	0.8
Replace	Front Suspension > Both Sides	B	2.5	1.2
Replace	Rear Suspension > One Side	C	1.3	1.0
Replace	Rear Suspension > Both Sides	C	1.8	1.3

## Front Suspension (Article 1383520)

Non Standards

- Front Shock Absorber and Coil Spring Disassembly/Assembly (1383521)

## Front Suspension (Article 1383489)

Non Standards

- Front Shock Absorber and Coil Spring Removal/Installation (1383492)