

# **Component Procedures: Power Steering Pressure Switch**

## **Table of Contents**


1. Components (itype\_32)

# Component Procedures: Power Steering Pressure Switch

## Components (itype\_32)

CONTROL SYSTEM LOCATION INDEX(LF, L3)

001405884100



03/14044027

1	HC2S
2	ECT sensor
3	APP sensor
4	CPP switch (MTX)

5	CMP sensor
6	PCM (built-in BARO sensor)
7	CKP sensor

8	KS
9	MAP sensor
10	TP sensor

11	Neutral switch (MTX)
12	MAF/IAT sensor