

Component Procedures: Trunk / Liftgate Switch

Table of Contents

1. Rear Compartment Lid Release Switch Replacement (Article 10493)

Component Procedures: Trunk / Liftgate Switch

Rear Compartment Lid Release Switch Replacement (Article 10493)

Callout Component Name

Preliminary Procedure Front Side Door Trim Panel Replacement

Preliminary Procedure

Front Side Door Trim Panel Replacement

1 Rear Compartment Lid Release Switch Procedure From the backside of the door trim panel , use a plastic trim tool to gently push in on the side tabs to release the switch from the front side door trim panel. Disconnect the electrical connector.

Procedure

- From the backside of the door trim panel , use a plastic trim tool to gently push in on the side tabs to release the switch from the front side door trim panel.
- Disconnect the electrical connector.