

Component Procedures: Suspension Control Module

Table of Contents

1. Suspension Control Module Replacement (Article 13526)

Component Procedures: Suspension Control Module

Suspension Control Module Replacement (Article 13526)

Callout Component Name

Preliminary Procedure Remove the rear compartment side trim panel. Refer to Rear Compartment Side Trim Panel Replacement .

Preliminary Procedure

Remove the rear compartment side trim panel. Refer to Rear Compartment Side Trim Panel Replacement .

1 Electronic Suspension Control Module Procedure Disconnect the electrical connector Release the lock tab for the control module . Remove the control module from the mounting bracket. Reprogram the control module. Refer to Electronic Suspension Control Module Programming and Setup

Procedure

- Disconnect the electrical connector
- Release the lock tab for the control module .
- Remove the control module from the mounting bracket.
- Reprogram the control module. Refer to Electronic Suspension Control Module Programming and Setup