

Component Procedures: High Pressure Sensor / Switch

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: High Pressure Sensor / Switch

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Switches & Sensors > High Pressure Switch, R&R	B	1.2	0.0