

Component Procedures: Fluid Line/Hose

Table of Contents

1. Parts and Labor (itype_189)
2. 6L45/6L50/6L80/6L90 (MYB, MYC, MYD) - Automatic Transmission (Article 11878)

Component Procedures: Fluid Line/Hose

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Oil Cooler > Coolant Line, R&R > Both	B	2.0	0.0
Remove & Replace	Oil Cooler > Coolant Line, R&R > Lower	B	1.6	0.0
Remove & Replace	Oil Cooler > Coolant Line, R&R > Upper	B	1.6	0.0

6L45/6L50/6L80/6L90 (MYB, MYC, MYD) - Automatic Transmission (Article 11878)

Non Standards

- Transmission Fluid Cooler Hose/Pipe Quick-Connect Fitting Disconnection and Connection (11879)
- Transmission Fluid Cooler Pipe Seal Replacement (13974)
- Transmission Fluid Cooler Hose/Pipe Replacement (13961)
- Transmission Fluid Cooler Inlet Pipe Replacement (13962)
- Transmission Fluid Cooler Outlet Pipe Replacement (13963)
- Transmission Fluid Cooler Pipe Replacement - Differential Cooler Inlet Hose/Pipe to Cooler Pipe (LSA) (13969)
- Transmission Fluid Cooler Pipe Replacement - Differential Cooler Outlet Hose/Pipe to Cooler Pipe (LSA) (13971)
- Transmission Fluid Cooler Pipe Replacement - Cooler Outlet Pipe to Differential Cooler Hose/Pipe (LSA) (13967)
- Transmission Fluid Cooler Pipe Replacement - Cooler Inlet Pipe to Differential Cooler Hose/Pipe (13964)