

Component Procedures: Air Bypass Valve

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Air Bypass Valve

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Supercharger > By-Pass Valve, R&R	B	0.5	0.0