

Component Procedures: Alternator Relay

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Alternator Relay

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Alternator > Relay, R&R	B	0.3	0.0