

Component Procedures: Axle Shaft

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Axle Shaft

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Rear Axle > Axle Assembly > ?	22813175	1 - Axle Assy	0.00	
Rear Axle > Axle Assembly > ?	22813176	1 - Axle Assy	0.00	
Rear Axle > Axle Assembly > ?	22813174	1 - Axle Assy	0.00	
Rear Axle > Axle Assembly > ?	22813173	1 - Axle Assy	0.00	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Replace	Rear Axle > One Side	B	1.8	1.4
Replace	Rear Axle > One Side > NOTE > To R&R Axle Sha?	B	0.2	0.0
Replace	Rear Axle > One Side > NOTE > To R&R Inner Jo?	B	0.5	0.0
Replace	Rear Axle > One Side > NOTE > To R&R Outer Jo?	B	0.5	0.0
Replace	Rear Axle > Both Sides	B	3.3	0.0
Replace	Rear Axle > Both Sides > NOTE > To R&R Axle S?	B	0.2	0.0
Replace	Rear Axle > Both Sides > NOTE > To R&R Inner ?	B	0.5	0.0
Replace	Rear Axle > Both Sides > NOTE > To R&R Outer ?	B	0.5	0.0