

Component Procedures: Marker Lamp Bulb

Table of Contents

1. Parts and Labor (itype_189)
2. Front Side Marker Lamp Bulb Replacement (Article 10395)
3. Rear Side Marker Lamp Bulb Replacement (Article 10413)

Component Procedures: Marker Lamp Bulb

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Bulbs > Exterior Bulbs, R&R > Front Side Mark?	C	0.5	0.4
Remove & Replace	Bulbs > Exterior Bulbs, R&R > Rear Side Marke?	C	0.3	0.3

Front Side Marker Lamp Bulb Replacement (Article 10395)

Callout Component Name

Preliminary Procedure Remove the front side marker lamp assembly. Refer to Front Side Marker Lamp Replacement

Preliminary Procedure

Remove the front side marker lamp assembly. Refer to Front Side Marker Lamp Replacement .

1 Front Side Marker Lamp Bulb Tip: Pull the marker lamp bulb straight out of the lamp socket.

Rear Side Marker Lamp Bulb Replacement (Article 10413)

Callout Component Name

Preliminary Procedure Remove the rear side marker lamp . Refer to Rear Side Marker Lamp Replacement .

Preliminary Procedure

Remove the rear side marker lamp . Refer to Rear Side Marker Lamp Replacement .

1 Rear Side Marker Lamp Socket Tip: Rotate and remove the lamp bulb socket from the lamp assembly.

2 Rear Side Marker Lamp Bulb Tip: Pull the bulb straight out of the lamp socket.