

# **Component Procedures: Engine Accessory Bracket**

## **Table of Contents**

1. Generator Bracket Replacement (LFX) (Article 11955)

# Component Procedures: Engine Accessory Bracket

## Generator Bracket Replacement (LFX) (Article 11955)

Callout Component Name

Preliminary Procedure Remove the generator. Refer to Generator Replacement .

Preliminary Procedure

Remove the generator. Refer to Generator Replacement .

1 Generator Bracket Fasteners (Qty: 3) Caution: Refer to Fastener Caution . Tighten 22 Nm (16 lb ft)

2 Generator Bracket Fasteners (Qty: 2) Tighten 58 Nm (43 lb ft)

58 Nm (43 lb ft)

3 Generator Bracket