

# **Component Procedures: Evaporator Drain Tube**

## **Table of Contents**

1. Parts and Labor (itype\_189)
2. Air Conditioning Evaporator and Blower Case Drain Replacement (Article 12714)
3. All Technical Service Bulletins (itype\_100)
4. Customer Interest Bulletins (itype\_109)

# Component Procedures: Evaporator Drain Tube

## Parts and Labor (itype\_189)

### Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Air Conditioner > Evaporator Tube, R&R	B	0.7	0.4

## Air Conditioning Evaporator and Blower Case Drain Replacement (Article 12714)

### Removal Procedure

- Raise and support the vehicle. Lifting and Jacking the Vehicle
- Propeller Shaft @ Transmission » Remove — Two-Piece Propeller Shaft Replacement Click for full-size image
- Support the transmission with a suitable jack.
- Transmission Support Crossmember (4) » Remove — Transmission Mount Replacement Click for full-size image
- Lower the transmission slowly to gain access to the air conditioning evaporator and blower case drain.
- Air Conditioning Evaporator and Blower Module Case Drain (1) » Remove Click for full-size image

### Installation Procedure

- Air Conditioning Evaporator and Blower Module Case Drain (1) » Install Click for full-size image
- Raise the transmission to it's proper position.
- Transmission Support Crossmember (4) » Install — Transmission Mount Replacement Click for full-size image
- Remove the transmission jack.
- Propeller Shaft @ Transmission » Install — Two-Piece Propeller Shaft Replacement Click for full-size image
- Remove the support and lower the vehicle. Lifting and Jacking the Vehicle

## All Technical Service Bulletins (itype\_100)

### Tsbs

- A/C - Moisture From Center Vent with A/C ON (09-01-38-003D, 2014/09/09)

## Customer Interest Bulletins (itype\_109)

### Tsbs

- A/C - Moisture From Center Vent with A/C ON (09-01-38-003D, 2014/09/09)