

# **Component Procedures: Coolant Line/Hose**

## **Table of Contents**

1. Engine Coolant Air Bleed Hose Replacement (LFX) (Article 11859)

## **Component Procedures: Coolant Line/Hose**

### **Engine Coolant Air Bleed Hose Replacement (LFX) (Article 11859)**

Callout Component Name

Preliminary Procedures Drain the engine cooling system . Refer to Cooling System Draining and Filling . Remove front intake manifold cover . Refer to Intake Manifold Cover Replacement - Front . Remove air cleaner outlet duct. Refer to Air Cleaner Outlet Duct Replacement .

Preliminary Procedures

- Drain the engine cooling system . Refer to Cooling System Draining and Filling .
- Remove front intake manifold cover . Refer to Intake Manifold Cover Replacement - Front .
- Remove air cleaner outlet duct. Refer to Air Cleaner Outlet Duct Replacement .

1 Engine Coolant Air Bleed Hose Clamp (Qty: 2) Procedure Reposition engine coolant air bleed hose clamp using J 38185 - Hose Clamp Pliers . Special Tools J 38185 - Hose Clamp Pliers

Procedure

Reposition engine coolant air bleed hose clamp using J 38185 - Hose Clamp Pliers .

Special Tools

J 38185 - Hose Clamp Pliers

2 Engine Coolant Air Bleed Hose