

Component Procedures: Trunk / Liftgate Handle

Table of Contents

1. Rear Compartment Lid Inside Handle Replacement (Article 10490)

Component Procedures: Trunk / Liftgate Handle

Rear Compartment Lid Inside Handle Replacement (Article 10490)

Callout Component Name

Preliminary Procedure Remove the rear compartment lid carpet . Refer to Rear Compartment Lid Carpet Replacement .

Preliminary Procedure

Remove the rear compartment lid carpet . Refer to Rear Compartment Lid Carpet Replacement .

1 Rear Compartment Lid Inside Latch Handle Access Cover Procedure Depress the retainers and slide the access cover to access the cable.

Procedure

Depress the retainers and slide the access cover to access the cable.

2 Rear Compartment Lid Inside Latch Handle Cable Procedure Disconnect the rear compartment lid inside latch handle cable from the latch.

Disconnect the rear compartment lid inside latch handle cable from the latch.

3 Rear Compartment Lid Inside Latch Handle Cable Retainer

4 Rear Compartment Lid Inside Latch Handle