

Component Procedures: Cabin Air Filter / Purifier

Table of Contents

1. Parts and Labor (itype_189)
2. Passenger Compartment Air Filter Replacement (Article 12756)

Component Procedures: Cabin Air Filter / Purifier

Parts and Labor (itype_189)

Parts

Qualifier	Part #	Name	Price	Note
Cabin Air Filter	92234714	Cabin Air Filter	0.00	

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Blower Motor > Air Filter, R&R	B	0.2	0.0

Passenger Compartment Air Filter Replacement (Article 12756)

Callout Component Name

Preliminary Procedure Remove air inlet grille panel. Refer to Air Inlet Grille Panel Replacement .

Preliminary Procedure

Remove air inlet grille panel. Refer to Air Inlet Grille Panel Replacement .

1 Passenger Compartment Air Filter Service Lid Retainer Procedure Release the retainer and open the service lid.

Procedure

Release the retainer and open the service lid.

2 Passenger Compartment Air Filter