

Component Procedures: Supercharger Coolant Pump

Table of Contents

1. Parts and Labor (itype_189)

Component Procedures: Supercharger Coolant Pump

Parts and Labor (itype_189)

Labor

Operation	Qualifier Path	Skill	Std Hrs	Wty Hrs
Remove & Replace	Intercooler > Hoses, R&R > To Pump	B	3.0	0.0
Remove & Replace	Intercooler > Pump, R&R > Intercooler Coolant	B	3.4	0.0